



BOWMAC LIFTER

Description:

Bowmac Lifting Chains specifically for lifting Bowmacs from level crossing installations.



Fastline Fred's Tips:

- Always check that the unit is in date before use.
- In case of breakdown call the Fastline Control Centre – 0845 450 2045

Fastline Limited

Marshgate Depot, Friarsgate, Greyfriars Road, Doncaster, DN1 1QV
T: +44 (0) 1302 303 555 F: +44 (0) 1302 303 564
E: info@fastline-group.com

